

Before Moving Trailer Out of Storage

- Inflate tires to proper level.
- Inspect tires for tread depth, uneven wear, cracking, bubbles.
- Check tire age (professional inspection required at five years, timed out at seven years).
- Torque lug nuts to factory specification.
- Confirm operation of tire-pressure monitoring system.
- Set mirrors on tow vehicle.
- Grease hitch ball or kingpin/saddle (or attach lube plate and grease kingpin).
- Hitch up trailer.
- Secure safety chains.
- Attach breakaway-switch cable.
- Attach sway control if equipped.
- Connect power cable.
- Check brake-, tail-, signal and clearance lights.
- Confirm trailer brakes are working.
- Adjust brake control as needed.
- Secure interior doors including refrigerator and cabinets.
- Secure exterior compartment doors.
- Secure patio awning.
- Make sure antennas are down.
- Check for updated registration and license-plate tags.

From the experts at:

TRAILER
FOLLOW THE ROAD TO ADVENTURE **LIFE**