

## **Tow Vehicle**

- Inspect the hitch receiver for rust and wear.
- Check the tire condition and tread depth.
- Inflate the tires (cold) for towing service.
- Check the engine oil.
- Check the transmission fluid.
- Check mirror adjustment and function.
- Check the windshield for cracks and chips.
- Run the windshield wipers and washer.
- Check windshield-wiper condition.
- Turn on headlights at night to check alignment.
- Check the function of the four-/seven-way receptacle.

From the experts at:

**TRAILER**  
FOLLOW THE ROAD TO ADVENTURE **LIFE**